


How to control lamps to run the same function? (For MR16)

Connect as many lamps as your needs with the signal wire
(diagram is shown below)



Control any one of the lamps, and rest of them
will change at the same time